

How to change front anti roll bar bushes on **BMW 3 Coupe (E46)** –
replacement guide





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for:

BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Coupe (E46) 318Ci 1.9, BMW 3 Coupe (E46) 330xi 3.0, BMW 3 Coupe (E46) 320Ci 2.2, BMW 3 Coupe (E46) 325Ci 2.5, BMW 3 Coupe (E46) 316Ci 1.6, BMW 3 Coupe (E46) 318Ci 2.0, BMW 3 Coupe (E46) 330Cd 3.0, BMW 3 Coupe (E46) 320Cd 2.0, BMW 3 Coupe (E46) 330Ci 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Convertible (E46) 318Ci 2.0

CLUB.AUTODOC.CO.UK 1–9





REPLACEMENT: ANTI ROLL BAR BUSHES – BMW 3 COUPE (E46). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Drive socket # 16
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Phillips screwdriver
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-9








Replacement: anti roll bar bushes – BMW 3 Coupe (E46). AUTODOC recommends:

- Both stabilizer bushes should be replaced simultaneously.
- The replacement procedure is identical for the right and left stabilizer bushes.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR BUSHES – BMW 3 COUPE (E46). RECOMMENDED SEQUENCE OF STEPS:

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-9









4

Unscrew the wheel bolts.



Replacement: anti roll bar bushes – BMW 3 Coupe (E46). Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.



Unscrew the fasteners of the lower sound insulation. Use a Phillips screwdriver.



Remove the lower sound insulation.



CLUB.AUTODOC.CO.UK 4–9









Please note!

• Some cars are not equipped with the lower sound insulation.





Unscrew the fasteners of the stabilizer bush brackets. Use a drive socket #16. Use a ratchet wrench.



10 Remove the stabilizer bush brackets.



Remove the stabilizer bushes.

11



CLUB.AUTODOC.CO.UK 5-9









12 Install the new stabilizer bushes.



Clean the mounting seats of the stabilizer bushes. Use WD-40 spray.



14 Install the stabilizer bush brackets.



Screw the fasteners of the stabilizer bush brackets. Use a drive socket #16. Use a torque wrench. Tighten it to 28 nm torque.



Install the lower sound insulation.

16



CLUB.AUTODOC.CO.UK 6-9







Screw in the fasteners of the lower sound insulation. Use a Phillips screwdriver.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



19 Install the wheel.



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. BMW 3 Coupe (E46)
- Screw in the wheel bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 7–9









21

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.



22

Remove the jacks and chocks.







VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 8-9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

ANTI ROLL BAR BUSHES: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 9-9