






VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 3 Convertible (E93) 325d 3.0, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Touring (E91) 330i 3.0, BMW 3 Saloon (E90) 330d 3.0, BMW 3 Touring (E91) 330d 3.0, BMW 3 Saloon (E90) 330xi 3.0, BMW 3 Saloon (E90) 330xd 3.0, BMW 3 Touring (E91) 330xi 3.0, BMW 3 Touring (E91) 330xd 3.0, BMW 3 Coupe (E92) 335i 3.0, BMW 3 Saloon (E90) 335i 3.0, BMW 3 Touring (E91) 335i 3.0, BMW 3 Coupe (E92) 335d 3.0, BMW 3 Touring (E91) 335d 3.0, BMW 3 Saloon (E90) 335d 3.0, (+ 29)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–17







REPLACEMENT: BRAKE DISCS – BMW E92. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- HEX bit No.H5.
- HEX bit No.H7.
- Drive socket # 17
- Wheel impact socket #17
- Brake caliper wind back tool

- Ratchet wrench
- Torque wrench
- Tap wrench
- Crow bar
- Impact screwdriver
- Rubber mallet
- Fender cover
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-17







Replacement: brake discs – BMW E92. Tip from AUTODOC experts:

- Replace the brake disks on the car BMW E92 in complete set for each axis.
 Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- Warning! Shut down the engine before starting any work BMW E92.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the bonnet.



2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



CLUB.AUTODOC.CO.UK 3-17







Remove the wiper arm cover.



Unscrew the brake fluid reservoir cap.



- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



CLUB.AUTODOC.CO.UK 4-17







8 Unscrew the wheel bolts.



Replacement: brake discs – BMW E92. AUTODOC recommends:

• To avoid injury, hold up the wheel when unscrewing the bolts.

9 Remove the wheel.

11



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Disconnect the brake pads wear sensor. Use a crowbar.



CLUB.AUTODOC.CO.UK 5-17







Please note!

• Some cars are not equipped with the brake pad wear sensor.





Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



15 Remove the brake caliper.



CLUB.AUTODOC.CO.UK 6-17








Replacement: brake discs – BMW E92. AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

16

Remove the brake pads.



17

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 7–17







Unscrew the caliper bracket fastening. Use a drive socket #17. Use a tap wrench.



19 Remove the caliper bracket.

21



Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the brake disc fastening. Use HEX No.H5. Use an impact screwdriver.



CLUB.AUTODOC.CO.UK 8-17







Remove the brake disc.



Replacement: brake discs – BMW E92. Tip from AUTODOC:

- If necessary, use a rubber mallet.
- Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.
- 24 Install the brake disc.



Tighten the brake disc fastening. Use HEX No.H5. Use a torque wrench. Tighten it to 16 Nm torque.



CLUB.AUTODOC.CO.UK 9-17







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake discs BMW E92. After applying the spray, wait a few minutes.
- Install the brake caliper bracket.

26

28



Tighten the brake caliper bracket. Use a drive socket #17. Use a torque wrench. Tighten it to 65 Nm torque.



CLUB.AUTODOC.CO.UK 10-17