




#### **VIDEO TUTORIAL**



### i Important!

This replacement procedure can be used for:

BMW 3 Saloon (E46) 318i 1.9, BMW 3 Saloon (E46) 328i 2.8, BMW 3 Saloon (E46) 320d 2.0, BMW 3 Saloon (E46) 323i 2.5, BMW 3 Saloon (E46) 320i 2.0, BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Saloon (E46) 316i 1.9, BMW 3 Touring (E46) 320i 2.0, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Coupe (E46) 318i 1.9, BMW 3 Touring (E46) 328i 2.8, BMW 3 Touring (E46) 320d 2.0, BMW 3 Saloon (E46) 330d 2.9, (+ 43)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-10



# REPLACEMENT: BRAKE PAD WEAR SENSOR – BMW E46 TOURING. TOOLS YOU'LL NEED:



- Wire brush
- Brake cleaner
- Electronic spray
- Copper grease

- Torque wrench
- Wheel impact socket #17
- Round-nose pliers
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-10





# Replacement: brake pad wear sensor – BMW E46 Touring. AUTODOC experts recommend:

- The replacement procedure is identical for both brake pad wear sensors on the same axle.
- Please note: all work on the car BMW E46 Touring should be done with the engine switched off.

#### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Open the bonnet. Unscrew the brake fluid reservoir cap.



- 2 Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Lift the car using a jack or place it over an inspection pit.



CLUB.AUTODOC.CO.UK 3-10







5 Unscrew the wheel bolts.



### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
  BMW E46 Touring
- Remove the wheel.

8



Remove the brake pad wear sensor from the brake pad. Use round-nose pliers.



Disconnect the brake pad wear sensor wire.

CLUB.AUTODOC.CO.UK 4-10







Open the cover of the wiring housing.



Detach the connector of the brake pad wear sensor.



Install the wear sensor on the brake pads. Use round-nose pliers.



Connect the brake pad wear sensor wire.

13



Treat the brake pad wear sensor plug. Use dielectric grease.



CLUB.AUTODOC.CO.UK 5-10







Attach the connector of the brake pad wear sensor.



Close the wiring housing cover.



Clean the wheel rim mounting seat. Use a wire brush.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.

18



CLUB.AUTODOC.CO.UK 6-10





#### **AUTODOC** recommends:

 Replacement: brake pad wear sensor – BMW E46 Touring. After applying the spray, wait a few minutes.

19

Install the wheel.



## AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E46 Touring
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



CLUB.AUTODOC.CO.UK 7-10







Remove the jacks and chocks.

23



Tighten the brake fluid reservoir cap. Close the hood.





**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 8-10





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**BUY SPARE PARTS FOR BMW** 

**BRAKE PAD WEAR SENSOR: A WIDE SELECTION** 

CLUB.AUTODOC.CO.UK 9-10