






VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

BMW 5 Saloon (E39) 520i 2.0, BMW 5 Saloon (E39) 523i 2.5, BMW 5 Saloon (E39) 528i 2.8, BMW 7 (E38) 728i / iL 2.8, BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 3 Saloon (E46) 328i 2.8, BMW 5 Touring (E39) 528i 2.8, BMW 3 Saloon (E46) 323i 2.5, BMW 3 Saloon (E46) 320i 2.0, BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Touring (E46) 320i 2.0, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Touring (E46) 328i 2.8, (+ 33)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–10







REPLACEMENT: SERPENTINE BELT – BMW E39. TOOLS YOU'LL NEED:



- Combination spanner #13
- Combination spanner #32
- Drive socket # 16

- Ratchet wrench
- Torque wrench
- Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-10







Replacement: serpentine belt – BMW E39. AUTODOC recommends:

• All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – BMW E39. USE THE FOLLOWING PROCEDURE:

Open the bonnet.

3



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Unscrew the fastener of the viscous fan clutch. Use a combination spanner #32.



CLUB.AUTODOC.CO.UK 3-10








4 Remove the fan shroud seal.



Unscrew and remove the viscous fan clutch.



6 Remove the fan shroud.



Pull aside the AC compressor belt tensioner pulley. Use a combination spanner #13.



Remove the AC compressor belt.



CLUB.AUTODOC.CO.UK 4-10







9 Remove the tensioner pulley cap.



Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #16. Use a ratchet wrench.



11 Remove the V-ribbed belt.

12



Return the tensioner pulley to its initial position. Use a drive socket #16. Use a ratchet wrench.



Replacement: serpentine belt – BMW E39. Professionals recommend:

 Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

CLUB.AUTODOC.CO.UK 5-10








Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #16. Use a ratchet wrench.



14 Install the V-ribbed belt.



Replacement: serpentine belt – BMW E39. Tip from AUTODOC:

- Make sure that the V-ribbed belt fits all pulleys snugly.
- Return the tensioner pulley to its initial position. Use a drive socket #16. Use a ratchet wrench.



Reinstall the tensioner pulley cap.



CLUB.AUTODOC.CO.UK 6-10







17 Install the AC compressor belt.



Replacement: serpentine belt – BMW E39. Tip:

- Make sure that the V-ribbed belt fits all pulleys snugly.
- Return the tensioner pulley to its initial position. Use a combination spanner #13.



19 Install the fan shroud.



Install and screw in the viscous fan clutch.



CLUB.AUTODOC.CO.UK 7-10







Tighten the fastener of the viscous fan clutch. Use a combination spanner #32. Use a torque wrench. Tighten it to 40 nm torque.



Reinstall the fan shroud seal.



Remove the fender protection cover.



Close the hood.





VIEW MORE TUTORIALS


CLUB.AUTODOC.CO.UK 8-10







AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

SERPENTINE BELT: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 9-10