









## i Important!

This replacement procedure can be used for: BMW X5 (E53) 4.4 i, BMW X5 (E53) 3.0 d, BMW X5 (E53) 4.6 is, BMW X5 (E53) 3.0 i, BMW X5 (E53) 4.8 is

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–12







## REPLACEMENT: REAR UPPER ARM – BMW X5 E53. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #16
- Combination spanner #18
- Drive socket # 8
- Drive socket # 18

- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Crow bar
- Hydraulic transmission jack
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-12







## Replacement: rear upper arm – BMW X5 E53. Tip from AUTODOC experts:

- The replacement procedure is identical for the right and left upper control arms.
- All work should be done with the engine stopped.

# REPLACEMENT: REAR UPPER ARM – BMW X5 E53. RECOMMENDED SEQUENCE OF STEPS:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #19.



Raise the rear of the car and secure on supports.



CLUB.AUTODOC.CO.UK 3-12







4 Unscrew the wheel bolts.



## Replacement: rear upper arm – BMW X5 E53. Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.



6.1 Clean all joints of the arm. Use a wire brush.



6.2 Treat all joints of the arm. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 4–12







#### **AUTODOC** recommends:

 Replacement: rear upper arm – BMW X5 E53. After applying the spray, wait a few minutes.





Unscrew the rear upper arm fastener from the stub axle. Use a drive socket #8. Use a combination spanner #16. Use a ratchet wrench.



Unscrew the arm fastening to the beam. Use a drive socket #18. Use a combination spanner #18. Use a ratchet wrench.



Remove the fastening bolt. Use a crowbar.

10



CLUB.AUTODOC.CO.UK 5-12







11 Remove the ball joint from the knuckle.



Remove the rear upper arm. Use a crowbar.



Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



Mount the rear upper arm.



CLUB.AUTODOC.CO.UK 6-12







## Replacement: rear upper arm – BMW X5 E53. AUTODOC recommends:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.
- 15 Install the ball joint to the knuckle. Use a crowbar.



16 Install the control arm fasteners.



Tighten the arm fastening to the beam. Use a combination spanner #18. Use a torque wrench. Tighten it to 59 nm torque.



CLUB.AUTODOC.CO.UK 7-12







Support the arm. Use a hydraulic transmission jack.



Tighten the control arm fastener to the stub axle. Use a drive socket #16. Use a torque wrench. Tighten it to 56 nm torque.



Remove the support from under the arm.



#### **AUTODOC** recommends:

- Replacement: rear upper arm BMW X5 E53. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.

CLUB.AUTODOC.CO.UK 8-12







22 Install the wheel.



## Replacement: rear upper arm – BMW X5 E53. AUTODOC experts recommend:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

Screw in the wheel bolts. Use wheel impact socket #19.



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 140 nm torque.



CLUB.AUTODOC.CO.UK 9-12







25

Remove the jacks and chocks.





**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 10-12