





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: BMW 5 Saloon (E34) 518i 1.8

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E46) 318i 1.9

CLUB.AUTODOC.CO.UK 1-11







REPLACEMENT: ENGINE OIL AND FILTER – BMW 5 SALOON (E34). TOOLS YOU NEED:



- All-purpose cleaning spray
- Drive socket # 17
- Oil filter cup socket 86/16 F
- Ratchet wrench
- Torque wrench

- Flat Screwdriver
- Phillips screwdriver
- Oil drain pan
- Funnel
- Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-11







Replacement: engine oil and filter – BMW 5 Saloon (E34). AUTODOC experts recommend:

- Replace the oil filter every time when changing motor oil.
- · Wear gloves to prevent contact with hot liquid.
- Please note: all work on the car BMW 5 Saloon (E34) should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Lift the car using a jack or place it over an inspection pit.

Replacement: engine oil and filter – BMW 5 Saloon (E34). Tip:

- The vehicle must be on even keel, and if it is at an angle, the drain plug must be at the lowest point.
- Undo the fasteners of the oil pan lower cover. Use a Phillips screwdriver.



Remove the oil pan cover.

CLUB.AUTODOC.CO.UK 3-11







- Put a waste oil container with at least 5 l capacity under the drainage hole.
- Clean the area of the oil pan drainage hole. Use all-purpose cleaning spray.



Unscrew the drain plug. Use a drive socket #17. Use a ratchet wrench.



Drain the used oil.



Replacement: engine oil and filter – BMW 5 Saloon (E34). Tip from AUTODOC:

- Caution! The oil may be hot.
- Wait until the oil has completely drained from the drainage hole.

Clean the area of the oil pan drainage hole.

CLUB.AUTODOC.CO.UK 4-11







Screw in the new drainage plug and tighten it. Use a drive socket #17. Use a torque wrench. Tighten it to 27 Nm torque.



- Clean the area of the oil pan drainage hole. Use all-purpose cleaning spray.
- Reinstall the oil pan lower cover.



Tighten the fasteners of the oil pan lower cover. Use a Phillips screwdriver.



- Lower the car.
- 14 Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

CLUB.AUTODOC.CO.UK 5-11







16 Unscrew the oil filler plug.



Unscrew the oil filter. Use the 86/16 F socket. Use a ratchet wrench.



Put the old oil filter in the container.

20



Remove the filter element from the filter housing.



Remove old o-rings from the oil filter cover. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 6-11







- Clean the oil filter housing cap. Use all-purpose cleaning spray.
- Install new O-rings and a new oil filter to their mounting seats on the filter cover. Use a flat screwdriver.



Please note!

- Make sure to install the filter correctly. Don't mix up the sides of the part.
- Clean the oil filter seat.
- Lubricate the rubber seal of the new filter with a little amount of fresh oil.



Screw the new filter into its place. Use the 86/16 F socket. Use a torque wrench. Tighten it to 23 Nm torque.



CLUB.AUTODOC.CO.UK 7-11







Remove the oil filler cap.



- 27 Insert the funnel.
- Pour new oil into the engine in the amount recommended by the car manufacturer.



Replacement: engine oil and filter – BMW 5 Saloon (E34). Professionals recommend:

- Use the oil recommended by the manufacturer.
- Check the oil level using the dipstick. Top up oil if necessary.



CLUB.AUTODOC.CO.UK 8-11







Please note!

• The oil level should be between the Min and Max marks.

30 Install the oil filler cap.



- Tighten the oil filler cap.
- Run the engine for a few minutes. After the oil pressure warning light goes out, stop the engine.
- Check the oil level 5 minutes after the stop of the engine operation using a dipstick and add oil if necessary.



Please note!

- The oil level should be between the Min and Max marks.
- Make sure that the oil filler cap is properly tightened.
- Check the threaded plug of the drainage hole and the oil filter seal for tightness. If necessary, carefully tighten them up.

CLUB.AUTODOC.CO.UK 9-11







34

Remove the fender protection cover. Close the hood.

Replacement: engine oil and filter – BMW 5 Saloon (E34). AUTODOC experts recommend:

- Note that oil pressure warning light, which indicates insufficient pressure in the lubrication system, may be on for a longer time than usual. After a few seconds, the oil will fill all the channels, and the light will go out.
- To protect the environment from pollution, be sure to dispose of the used filters at special collection points.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-11