









i Important!

This replacement procedure can be used for:

BMW X3 (E83) xDrive 20 d, BMW X3 (E83) xDrive 30 d, BMW X3 (E83) 3.0 i xDrive, BMW X3 (E83) 3.0 d, BMW X3 (E83) 2.0 d, BMW X3 (E83) 2.0 i, BMW X3 (E83) 3.0 si, BMW X3 (E83) 2.5 si, BMW X3 (E83) 3.0 sd, BMW X3 (E83) xDrive 20 i, BMW X3 (E83) xDrive 25 i, BMW X3 (E83) xDrive 30 i, BMW X3 (E83) xDrive 18 d, BMW X3 (E83) xDrive 35 d

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-23







REPLACEMENT: STRUT MOUNT – BMW X3 E83. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #17
- Drive socket # 10
- Drive socket # 13
- Drive socket # 16
- Drive socket # 18
- Torx bit T20

- Torx bit T25
- Shock absorber socket #DD6
- Wheel impact socket #17
- Ratchet wrench
- Adjustable wrench
- Plastic trim tool
- Phillips screwdriver
- Tap wrench
- Vice
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-23







Replacement: strut mount – BMW X3 E83. Tip from AUTODOC experts:

- The replacement procedure is identical for the mounts of the right and left shock absorbers of the rear suspension.
- Both mounts of the rear shock struts should be replaced simultaneously.
- Please note: all work on the car BMW X3 E83 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the boot lid.



Move the folding shelf and detach it from the retainers. By doing this, you will get access to the side trim plastic panels.



Fold down the backrests of the rear seats.



CLUB.AUTODOC.CO.UK 3-23







Raise the lower lining of the boot.



5 Detach the boot side lining.



6 Unscrew the fasteners of the plastic car body protective cover. Use a Phillips screwdriver.



7 Remove the rubber strip.

8



Remove the plastic car body protective cover.



CLUB.AUTODOC.CO.UK 4-23







9 Remove the interior boot light.



10 Remove the seat belt trim cover.



- Detach the boot rear side lining.
- Unscrew the fasteners of the side plastic trim panel. Use a drive socket #10. Use a ratchet wrench.



Remove the clips from the parcel shelf. Use Torx T25. Use a ratchet wrench.



Detach the parcel shelf.

CLUB.AUTODOC.CO.UK 5-23







Remove the airbag cover. Use a plastic trim tool.



- Unscrew the fastener of the body pillar trim panel. Use Torx T20. Use a ratchet wrench.
- Remove the body pillar trim panel.



Unscrew the fasteners of the seat belt panel. Use a Phillips screwdriver.



19 Remove the seat belt panel.



CLUB.AUTODOC.CO.UK 6-23







20 Remove the side plastic cover.



- Detach the boot side lining.
- Remove the clips of the boot side lining. Use a plastic trim tool.
- Unscrew the fastener of the boot side lining. Use a Phillips screwdriver.



24 Detach the boot side lining.

25



Remove the protective cap of the shock absorber mount.



CLUB.AUTODOC.CO.UK 7-23







Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



Loosen the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.



- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



CLUB.AUTODOC.CO.UK 8-23







Unscrew the wheel bolts.



AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW X3 E83

Remove the wheel.

33

34



Support the arm. Use a hydraulic transmission jack.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 9-23







Unscrew the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.



Unscrew the lower fastener of the shock absorber. Use a drive socket #18. Use a tap wrench.



Remove the fastening bolt.

AUTODOC recommends:

- BMW X3 E83 To avoid injury, hold the shock absorber while unscrewing the fastening bolts.
- Remove the shock absorber.



Grip the shock absorber in a vice.

CLUB.AUTODOC.CO.UK 10-23