





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: BMW Z4 Roadster (E85) 3.0 i, BMW Z4 Roadster (E85) 2.5 i, BMW Z4 Roadster (E85) 2.2 i

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E39) 520i 2.0

CLUB.AUTODOC.CO.UK 1-6







REPLACEMENT: AIR FILTER – BMW Z4 ROADSTER (E85). TOOLS YOU NEED:



Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-6







AUTODOC recommends:

- Replacement: air filter BMW Z4 Roadster (E85). Do not ignore the maintenance schedule, recommendations, and requirements specified by the manufacturer on the use of the car part.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – BMW Z4 ROADSTER (E85). USE THE FOLLOWING PROCEDURE:

- Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Release the air filter cover clips.



Remove the air filter housing.

4



CLUB.AUTODOC.CO.UK 3-6







Clean the air filter cover and housing.



Replacement: air filter – BMW Z4 Roadster (E85). Tip from AUTODOC experts:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.
- Remove the filter element from the filter housing.



Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



CLUB.AUTODOC.CO.UK 4-6







AUTODOC recommends:

- Replacement: air filter BMW Z4 Roadster (E85). Be sure to position the filtering element correctly. Avoid misalignment.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.
- Take care to only use quality filters.

Reinstall the air filter housing.



o Press the air filter cover clips into place.



- Remove the fender protection cover.
- Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 5-6