

How to change air filter on **BMW E46**convertible –

replacement guide





#### **VIDEO TUTORIAL**



### i Important!

This replacement procedure can be used for:

BMW 3 Compact (E46) 316ti 1.8, BMW 3 Compact (E46) 318ti 2.0, BMW 3 Saloon (E46) 318i 2.0, BMW 3 Coupe (E46) 318Ci 2.0, BMW 3 Saloon (E46) 316i 1.8, BMW 3 Touring (E46) 318i 2.0, BMW 3 Convertible (E46) 318Ci 2.0, BMW 3 Touring (E46) 316i 1.8, BMW 3 Saloon (E46) 316i 1.6, BMW 3 Coupe (E46) 316Ci 1.6, BMW 3 Compact (E46) 316ti 1.6, BMW 3 Compact (E46) 318Ti 2.0

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-10





## REPLACEMENT: AIR FILTER – BMW E46 CONVERTIBLE. TOOLS YOU NEED:



- Drive socket #8
- Drive socket # 10
- Ratchet wrench

- Phillips Screwdriver
- Fender cover

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-10





#### Replacement: air filter – BMW E46 convertible. AUTODOC experts recommend:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Please note: all work on the car BMW E46 convertible should be done with the engine switched off.

### **CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**

Open the bonnet.

2



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Remove the fasteners of the air duct housing. Detach the air duct housing from the air filter housing.



CLUB.AUTODOC.CO.UK 3-10







Loosen the fastening clamp connecting the air duct to the air filter housing. Remove the air intake hose. Use a 4 drive socket #8.



Unscrew the filter housing fastening bolts. Use a drive socket #10. 5



Remove the air filter housing. 6

8



Unplug the mass air flow sensor connector.



Undo the fastening screws of the air filter cover. Use a Phillips screwdriver.



CLUB.AUTODOC.CO.UK 4-10









Take off the filter lid.



Unscrew the fastener of the mass air flow sensor. Remove the part. Use a drive socket #10. Use a ratchet wrench.



Remove the filter element from the filter housing.



Clean the air filter cover and housing.



CLUB.AUTODOC.CO.UK 5-10





#### Replacement: air filter – BMW E46 convertible. Professionals recommend:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

13

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



#### **AUTODOC** recommends:

- Replacement: air filter BMW E46 convertible. Be sure to position the filtering element correctly. Avoid misalignment.
- Take care to only use quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

14

Install the mass air flow sensor. Screw the fastener of the part. Use a drive socket #10. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 6-10



18







Screw in the fastening screws of the air filter cover. Use a Phillips screwdriver.



Reinstall the air filter housing. Plug in the mass air flow sensor conntector.



Secure the air intake hose. Screw the fastening clamp connecting the air duct to the air filter housing. Use a drive socket #8.



Screw the filter housing fastening bolts. Use a drive socket #10. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 7-10









Install the air duct housing. Install the air duct housing fasteners.



Remove the fender protection cover.



Close the hood.






**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 8-10





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**BUY SPARE PARTS FOR BMW** 

**AIR FILTER: A WIDE SELECTION** 

CLUB.AUTODOC.CO.UK 9-10





#### **CHOOSE CAR PARTS FOR BMW E46 CONVERTIBLE**

AIR FILTER FOR BMW: BUY NOW

AIR FILTER FOR BMW E46 CONVERTIBLE: THE BEST DEALS & OFFERS

#### **① DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 10-10