









## i Important!

This replacement procedure can be used for: BMW X5 (E53) 3.0 d, BMW X5 (E53) 4.6 is, BMW X5 (E53) 3.0 i, BMW X5 (E53) 4.4 i

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–19







# REPLACEMENT: SUSPENSION STRUT – BMW X5 E53. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #19
- Combination spanner #21
- Combination spanner #22
- Drive socket # 10
- Drive socket # 13
- Drive socket # 22

- HEX bit no.H5.
- HEX bit no.H7.
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Hydraulic strut spring compressor
- Fender cover
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-19







## Replacement: suspension strut – BMW X5 E53. AUTODOC experts recommend:

- Both shock struts of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock struts of the front suspension.
- All work should be done with the engine stopped.

# REPLACEMENT: SUSPENSION STRUT – BMW X5 E53. TAKE THE FOLLOWING STEPS:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-19







4 Unscrew the wheel bolts.



## Replacement: suspension strut – BMW X5 E53. Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.

6



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 4–19







Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #19. Use HEX No.H5. Use a ratchet wrench.



- Remove the stabilizer rod.
- Detach the brake hose from the shock strut. Use a flat screwdriver.



- Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.
- Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #22. Use a drive socket #22. Use a ratchet wrench.



12 Remove the fastening bolt.



CLUB.AUTODOC.CO.UK 5-19







- Disconnect the ABS sensor wiring.
- 14 Remove the fastening bolt.
- Disconnect the steering knuckle from the shock absorber strut.



## Replacement: suspension strut – BMW X5 E53. AUTODOC recommends:

• Make sure that the steering knuckle is supported.

Lower the car.



Open the bonnet.

18



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

CLUB.AUTODOC.CO.UK 6-19







Unscrew the bolts and remove the windshield washer tank. Use a drive socket #10. Use a ratchet wrench.



- Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.
- Unscrew the top fastening of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.



#### **AUTODOC** recommends:

- Important! Hold the suspension strut while unscrewing the fastening bolts. BMW X5 E53
- Remove the suspension strut.



CLUB.AUTODOC.CO.UK 7–19







Set the shock absorber strut on the spring compressor tool.



#### Replacement: suspension strut – BMW X5 E53. Tip from AUTODOC:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.
- 24 Compress the spring.

23



- Treat the shock strut rod. Use a wire brush. Use WD-40 spray.
- Remove the strut piston rod nut. Use a combination spanner #21. Use HEX No.H7.



CLUB.AUTODOC.CO.UK 8-19







- Release the coil spring.
- Remove the top strut mount.
- Remove the spring.



Remove the shock absorber dust cap and the bump stop.



#### **AUTODOC** recommends:

- Replacement: suspension strut BMW X5 E53. Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.
- Remove the rubber spring spacer.



CLUB.AUTODOC.CO.UK 9-19







Remove the old shock absorber from the hydraulic coil spring compressor.



### Replacement: suspension strut – BMW X5 E53. Tip from AUTODOC experts:

- Before installing a new shock absorber you should pump it manually 3-5 times.
- Install the new shock absorber on the hydraulic coil spring compressor.
- 34 Install the rubber spring spacer.



Install the dust sleeve and the bump stop on the new shock absorber.



CLUB.AUTODOC.CO.UK 10-19