





### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

# (i) Important!

This replacement procedure can be used for: BMW 3 Compact (E46) 325ti 2.5, BMW 3 Compact (E46) 320td 2.0, BMW 3 Compact (E46) 318td 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Touring (E46) 330d 3.0

CLUB.AUTODOC.CO.UK 1–21







# REPLACEMENT: COIL SPRINGS – BMW 3 COMPACT (E46). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #17
- Combination spanner #19
- Combination spanner #21
- Drive socket # 13
- Drive socket # 18
- Drive socket # 21
- HEX bit no.H6
- HEX bit no.H7

- Wheel impact socket #17
- Shock absorber socket
- Ball joint puller
- Ratchet wrench
- Torque wrench
- Tap wrench
- Crow bar
- Hydraulic strut spring compressor
- Hydraulic transmission jack
- Fender cover
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-21







# Replacement: coil springs – BMW 3 Compact (E46). Tip from AUTODOC:

- Both coil springs of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right coil springs of the front suspension.
- Please note: all work on the car BMW 3 Compact (E46) should be done with the engine switched off.

### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Loosen the upper fastener of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.



Secure the wheels with chocks.



CLUB.AUTODOC.CO.UK 3-21







Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the front of the car and secure on supports.
- Unscrew the wheel bolts.



#### **AUTODOC** recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW 3 Compact (E46)

Remove the wheel.



CLUB.AUTODOC.CO.UK 4-21







Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the nut and remove the stabilizer rod from the shock strut. Use HEX No.H7. Use a combination spanner #17. Use a ratchet wrench.



Treat the retaining bracket that secures the brake hose and the wiring harness. Use WD-40 spray.



Disconnect the wiring and the brake hose from the bracket on the shock strut.



12

CLUB.AUTODOC.CO.UK 5-21







Clean the fasteners connecting the shock strut to the steering knuckle. Clean the fastener connecting the ball joint to the steering knuckle. Use a wire brush. Use WD-40 spray.



Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a drive socket #18. Use a tap wrench.



Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #19.



Support the arm. Use a hydraulic transmission jack.

16



CLUB.AUTODOC.CO.UK 6-21







Disconnect the ball joint from the steering knuckle. Use a ball joint puller.



Lower the hydraulic transmission jack by 10-15 cm.



#### **AUTODOC** recommends:

- Replacement: coil springs BMW 3 Compact (E46). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Disconnect the lower arm from the steering knuckle.



Prop up the steering knuckle. Use a hydraulic transmission jack.



20


CLUB.AUTODOC.CO.UK 7-21







Release the lower fastener connecting the shock strut to the steering knuckle. Use a special drive socket to remove the shock absorber.



Lower the hydraulic transmission jack by 10-15 cm.



#### **AUTODOC** recommends:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.
- Disconnect the steering knuckle from the shock absorber strut.



CLUB.AUTODOC.CO.UK 8-21







Unscrew the top fastening of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.



### **AUTODOC** recommends:

• BMW 3 Compact (E46) – To avoid injury, hold the suspension strut while unscrewing the fastening bolts.

Remove the suspension strut.

26



Set the shock absorber strut on the spring compressor tool.



CLUB.AUTODOC.CO.UK 9-21







## Replacement: coil springs – BMW 3 Compact (E46). Tip from AUTODOC:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.
- Remove the shock strut mount cap. Use a crowbar.



Compress the spring.

29



Treat the shock strut rod. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 10-21