






#### **VIDEO TUTORIAL**



#### (i) Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Saloon (E90) 320d xDrive 2.0, BMW 3 Convertible (E93) 325d 3.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Saloon (E90) 320d 2.0, BMW 3 Touring (E91) 325i 2.5, BMW 3 Touring (E91) 330i 3.0, BMW 3 Touring (E91) 320d 2.0, BMW 3 Saloon (E90) 330d 3.0, BMW 3 Touring (E91) 325xi 2.5, BMW 3 Saloon (E90) 330xi 3.0, BMW 3 Saloon (E90) 330xd 3.0, BMW 3 Touring (E91) 325xi 2.5, (+ 48)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-15







## REPLACEMENT: BRAKE PADS – BMW E92. TOOLS YOU NEED:



- Wire brush
- Brake cleaner
- Copper grease
- Anti-squeal paste
- HEX bit No.H7.
- Wheel impact socket #17

- Brake caliper wind back tool
- Ratchet wrench
- Torque wrench
- Crow bar
- Fender cover
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-15







#### Replacement: brake pads – BMW E92. AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This
  provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: BRAKE PADS – BMW E92. USE THE FOLLOWING PROCEDURE:

1

Open the bonnet.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Remove the wiper arm cover.



CLUB.AUTODOC.CO.UK 3-15







4 Unscrew the brake fluid reservoir cap.



- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



8 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 4-15







#### Replacement: brake pads – BMW E92. Professionals recommend:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Disconnect the brake pads wear sensor. Use a crowbar.



#### Please note!

• Some cars are not equipped with the brake pad wear sensor.

CLUB.AUTODOC.CO.UK 5-15







Detach the brake caliper retaining spring. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



Remove the brake caliper.



CLUB.AUTODOC.CO.UK 6-15







#### Replacement: brake pads – BMW E92. AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

16

Remove the brake pads.



#### Replacement: brake pads – BMW E92. Tip:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

CLUB.AUTODOC.CO.UK 7–15







17 Treat the brake caliper piston. Use a brake cleaner.



### Replacement: brake pads – BMW E92. Tip from AUTODOC:

• After applying the spray, wait a few minutes.

Press in the brake caliper piston. Use brake caliper wind back tool.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



19

#### **AUTODOC** recommends:

 Replacement: brake pads – BMW E92. After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 8-15







20

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



#### Replacement: brake pads – BMW E92. Tip from AUTODOC experts:

• Make sure the disc surface is clean before installing the pads.

21

Install new brake pads.



#### Replacement: brake pads – BMW E92. Professionals recommend:

• Make sure the pads are installed with linings facing the disc.

CLUB.AUTODOC.CO.UK 9-15







Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



23 Install the dust boot caps of the brake caliper guide pins.



Connect the brake pads wear sensor.

25

26



Install the brake caliper retaining spring. Use a crowbar.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



CLUB.AUTODOC.CO.UK 10-15