







This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: BMW Z4 Coupe (E86) 3.0 si, BMW Z4 Coupe (E86) M

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Touring (E46) 330d 3.0

CLUB.AUTODOC.CO.UK 1–9





REPLACEMENT: ANTI ROLL BAR LINKS – BMW Z4 COUPE (E86). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #17
- Drive socket # 17
- HEX bit no.H7

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Fender cover
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-9





AUTODOC recommends:

- Replace the stabiliser links on BMW Z4 Coupe (E86) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Warning! Shut down the engine before starting any work BMW Z4 Coupe (E86).

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3–9







6 Unscrew the wheel bolts.



AUTODOC recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. BMW Z4 Coupe (E86)

Remove the wheel.



8.1 Clean the stabiliser link fasteners.



8.2 Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 4–9







Unscrew the fastener connecting the stabilizer link to the shock strut. Use HEX No.H7. Use a combination spanner #17. Use a ratchet wrench.



Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use HEX No.H7. Use a combination spanner #17. Use a ratchet wrench.



11 Remove the stabilizer rod.

12



Install a new rod, tighten the fasteners.



CLUB.AUTODOC.CO.UK 5-9





Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a combination spanner #17. Use a torque wrench. Tighten it to 55 Nm torque.



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17. Use a combination spanner #17. Use a torque wrench. Tighten it to 55 Nm torque.



15.1 Treat all joints of the stabiliser link.



15.2 Use copper grease.



CLUB.AUTODOC.CO.UK 6–9







Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



17 Install the wheel.

18



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW Z4 Coupe (E86)

Screw in the wheel bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 7–9







Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



Remove the jacks and chocks.



Remove the fender protection cover.

Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 8-9