AUTODOC CLUB

How to change coolant hose on **BMW 3 Saloon** (**E46**) – replacement guide





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: BMW 3 Saloon (E46) 320d 2.0, BMW 3 Saloon (E46) 318d 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Touring (E46) 320d 2.0

CLUB.AUTODOC.CO.UK 1-11





REPLACEMENT: COOLANT HOSE – BMW 3 SALOON (E46). TOOLS YOU NEED:



- All-purpose cleaning spray
- Drive socket # 12
- HEX bit No.H5
- Ratchet wrench
- Flat screwdriver

- Funnel
- Fluid container
- Crow bar
- Fender cover
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-11





Replacement: coolant hose - BMW 3 Saloon (E46). AUTODOC recommends:

- Check the cooling circuit for leaks. Replace any worn parts.
- All work should be done with the engine stopped.

REPLACEMENT: COOLANT HOSE – BMW 3 SALOON (E46). TAKE THE FOLLOWING STEPS:

- Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Unscrew the fasteners of the air distribution housing assembly. Use a drive socket #12. Use a ratchet wrench.



Remove the air distribution housing assembly.



- Secure the wheels with chocks.
- 6 Lift the car using a jack or place it over an inspection pit.

CLUB.AUTODOC.CO.UK 3-11









Unscrew the engine cover fastener. Use HEX No.H5. Use a ratchet wrench.



Remove the engine cover.



AUTODOC recommends:

- Do not apply excessive force when removing the part. Otherwise you may damage it.
- Prepare a container for fluids.

10



Unscrew the coolant drain plug. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 4-11









Drain the coolant from the engine.



Replacement: coolant hose – BMW 3 Saloon (E46). Tip:

- Caution! The coolant can be very hot.
- Wear gloves to prevent contact with hot liquid.
- All work should be done with the engine stopped.
- Wait until the coolant has completely flowed out of the drain hole.

Unscrew the coolant reservoir cap.

13



Remove the coolant hose retainers. Use a crowbar.



CLUB.AUTODOC.CO.UK 5-11



16







Detach the coolant hose. Use a crowbar.



Replacement: coolant hose – BMW 3 Saloon (E46). Tip from AUTODOC experts:

- Be careful! The coolant may leak.
- Replacement: coolant hose BMW 3 Saloon (E46). To avoid damaging the part when removing it, do not use excessive force.
- Screw in the coolant drain plug. Use a flat screwdriver.



Clean the mounting seats of the coolant hose. Use all-purpose cleaning spray.



CLUB.AUTODOC.CO.UK 6-11









Connect the new coolant hose.



Fasten the retainers of the coolant hose.



19 Insert the funnel.

20



Pour coolant in the coolant reservoir.



AUTODOC recommends:

- Only use the coolant recommended by the manufacturer.
- The coolant level should be at the MAX mark.
- Wait until the air goes out of the system.

CLUB.AUTODOC.CO.UK 7-11









Unscrew the bleeder screws. Use a flat screwdriver.



Please note!

- This is necessary to remove any remaining air from the system.
- Screw in the bleeder screws. Use a flat screwdriver.



Check the coolant level. If necessary, top up to the required level.



Screw on the coolant reservoir cap.



CLUB.AUTODOC.CO.UK 8-11









25

Install the engine cover and secure it.



AUTODOC recommends:

 Replacement: coolant hose – BMW 3 Saloon (E46). To avoid damaging the part during installation, do not use excessive force.

Screw in the engine cover fasteners. Use HEX No.H5. Use a ratchet wrench.



Reinstall the air distribution housing assembly.



CLUB.AUTODOC.CO.UK 9-11







Screw in the fasteners of the air distribution housing assembly. Use a drive socket #12. Use a ratchet wrench.



- Lower the car.
- Remove the jacks and chocks.
- Remove the fender protection cover.
- Close the hood.




VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-11





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

COOLANT HOSE: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 11-11