









i Important!

This replacement procedure can be used for: BMW X5 (E53) 3.0 d, BMW X5 (E53) 4.4 i

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-19







REPLACEMENT: COIL SPRINGS – BMW X5 E53. TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #19
- Combination spanner #22
- Drive socket # 10
- Drive socket # 13
- Drive socket # 22

- HEX bit no.H5.
- HEX bit no.H7.
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Hydraulic strut spring compressor
- Fender cover
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-19







Replacement: coil springs – BMW X5 E53. AUTODOC recommends:

- Both coil springs of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right coil springs of the front suspension.
- All work should be done with the engine stopped.

REPLACEMENT: COIL SPRINGS – BMW X5 E53. RECOMMENDED SEQUENCE OF STEPS:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-19







4 Unscrew the wheel bolts.



Replacement: coil springs – BMW X5 E53. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



- 6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #19. Use HEX No.H5. Use a ratchet wrench.



Remove the stabilizer rod.

CLUB.AUTODOC.CO.UK 4–19







Detach the brake hose from the shock strut. Use a flat screwdriver.



Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.



Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #22. Use a drive socket #22. Use a ratchet wrench.



12 Remove the fastening bolt.



CLUB.AUTODOC.CO.UK 5–19







- Disconnect the ABS sensor wiring.
- Remove the fastening bolt.



Disconnect the steering knuckle from the shock absorber strut.



Replacement: coil springs – BMW X5 E53. AUTODOC experts recommend:

- Make sure that the steering knuckle is supported.
- Lower the car.
- Open the bonnet.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

CLUB.AUTODOC.CO.UK 6-19







Unscrew the bolts and remove the windshield washer tank. Use a drive socket #10. Use a ratchet wrench.



Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.



Unscrew the top fastening of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.



Replacement: coil springs – BMW X5 E53. Tip from AUTODOC:

• To avoid injuries, hold the shock strut when undoing the fastening bolts.

CLUB.AUTODOC.CO.UK 7-19







Remove the suspension strut.



23 Set the shock absorber strut on the spring compressor tool.



Replacement: coil springs – BMW X5 E53. Professionals recommend:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

24 Compress the spring.



CLUB.AUTODOC.CO.UK 8-19







Treat the shock strut rod. Use a wire brush. Use WD-40 spray.



Remove the strut piston rod nut. Use a combination spanner #22. Use HEX No.H7.



- Release the coil spring.
- Remove the top strut mount.



Remove the spring.



CLUB.AUTODOC.CO.UK 9-19







Remove the shock absorber dust cap and the bump stop.



AUTODOC recommends:

- Replacement: coil springs BMW X5 E53. Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.
- Install the spring on the shock absorber.



Install the boot and a bump stop onto the shock absorber.



Compress the spring.

32

CLUB.AUTODOC.CO.UK 10-19