






VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 3 Saloon (E90) 318d 2.0, BMW 3 Coupe (E92) 318i 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Saloon (E90) 320d 2.0, BMW 3 Saloon (E90) 330d 3.0, BMW 3 Saloon (E90) 320si 2.0, BMW 3 Saloon (E90) 335i 3.0, BMW 3 Saloon (E90) 335d 3.0, BMW 3 Coupe (E92) 325i 2.5, BMW 3 Coupe (E92) 330i 3.0, BMW 3 Coupe (E92) 330d 3.0, BMW 3 Coupe (E92) 325xi 2.5, BMW 3 Saloon (E90) 325d 3.0, (+ 16)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–12







REPLACEMENT: COIL SPRINGS – BMW E90. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #21
- Drive socket # E12
- Drive socket # 21

- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Crow bar
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-12







Replacement: coil springs – BMW E90. AUTODOC experts recommend:

- Both coil springs of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right coil springs of the rear suspension.
- Please note: all work on the car BMW E90 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-12







4 Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW E90
- 5 Remove the wheel.

6



Support the stub axle. Use a hydraulic transmission jack.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.

CLUB.AUTODOC.CO.UK 4–12







Unscrew the lower fastener of the shock absorber. Use a drive socket #E12. Use a ratchet wrench.



- Clean the control arm fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the control arm to the rear knuckle. Use a combination spanner #21. Use a drive socket #21. Use a ratchet wrench.



- Remove the fastening bolt. Use a flat screwdriver.
 - Remove the support from under the stub axle.



AUTODOC recommends:

• Replacement: coil springs – BMW E90. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 5-12







- Pull down the suspension control arm. Use a crowbar.
- Remove the spring.



Clean the coil spring mounting seats. Use a wire brush. Use WD-40 spray.



- Pull down the suspension control arm. Use a crowbar.
- 17 Install the spring.



Replacement: coil springs – BMW E90. Tip from AUTODOC experts:

• Make sure that the coil spring is correctly positioned in its mounting seats.

CLUB.AUTODOC.CO.UK 6-12







Support the stub axle. Use a hydraulic transmission jack.



Tighten the lower fastener of the shock absorber. Use a drive socket #E12. Use a torque wrench. Tighten it to 47 Nm torque.



- Treat the shock absorber fasteners. Use copper grease.
- Install the fastening bolt. Use a flat screwdriver.
- Tighten the fastener connecting the suspension arm to the rear knuckle. Use a combination spanner #21. Use a drive socket #21. Use a torque wrench. Tighten it to 100 Nm torque.



Treat the rear knuckle fasteners. Use copper grease.

23



CLUB.AUTODOC.CO.UK 7-12








Remove the support from under the stub axle.

AUTODOC recommends:

 BMW E90 – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.





Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

 Replacement: coil springs – BMW E90. After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 8-12







27 Install the wheel.



AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E90

Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



CLUB.AUTODOC.CO.UK 9-12







30

Remove the jacks and chocks.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-12