






# SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

# (i) Important!

This replacement procedure can be used for: BMW 8 (E31) 850i / Ci 5.0, BMW 8 (E31) 850Ci 5.4, BMW 8 (E31) 850CSi 5.6, BMW 8 (E31) 840Ci 4.4

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW X3 (E83) 2.5 i

CLUB.AUTODOC.CO.UK 1–13







# REPLACEMENT: BRAKE PADS – BMW 8 (E31). AUTODOC EXPERTS RECOMMEND:



- Wire brush
- Nylon cleaning brush
- Brake cleaner
- Copper grease
- Anti-squeal paste
- Torque wrench
- HEX bit No.H7

- Wheel impact socket #17
- Brake caliper wind back tool
- Ratchet wrench
- Round-nose pliers
- Crow bar
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-13







## Replacement: brake pads – BMW 8 (E31). Professionals recommend:

- Perform the replacement of brake pads in complete set for each axis. This
  provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: BRAKE PADS – BMW 8 (E31). RECOMMENDED SEQUENCE OF STEPS:

Open the bonnet. Unscrew the brake fluid reservoir cap.



- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-13







A Raise the rear of the car and secure on supports.



5 Unscrew the wheel bolts.



#### **AUTODOC** recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
   BMW 8 (E31)
- Remove the wheel.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



CLUB.AUTODOC.CO.UK 4–13







Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Disconnect the brake pads wear sensor. Use round-nose pliers.



Detach the brake caliper retaining spring. Use a crowbar.



Spread the brake pads. Use a crowbar.



12 Remove the brake caliper.



CLUB.AUTODOC.CO.UK 5-13







## Replacement: brake pads – BMW 8 (E31). Tip from AUTODOC experts:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them.
   Replace, if necessary.

13

Remove the brake pads.



# Replacement: brake pads - BMW 8 (E31). AUTODOC recommends:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

CLUB.AUTODOC.CO.UK 6-13







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



# **AUTODOC** recommends:

- Replacement: brake pads BMW 8 (E31). After applying the spray, wait a few minutes.
- Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.



#### **AUTODOC** recommends:

- After applying the spray, wait a few minutes.
- Press in the brake caliper piston. Use brake caliper wind back tool.



CLUB.AUTODOC.CO.UK 7–13







Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



# Replacement: brake pads – BMW 8 (E31). AUTODOC recommends:

• Make sure the disc surface is clean before installing the pads.

18 Install new brake pads.



# Replacement: brake pads – BMW 8 (E31). Tip from AUTODOC experts:

• Make sure the pads are installed with linings facing the disc.

Install the brake caliper and fix it.



CLUB.AUTODOC.CO.UK 8-13







20 Install the brake caliper retaining spring.



Tighten the brake caliper fasteners. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



Install the dust boot caps of the brake caliper guide pins.



Connect the brake pads wear sensor. Use round-nose pliers.



Clean the wheel rim mounting seat. Use a wire brush.

24



CLUB.AUTODOC.CO.UK 9-13







Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



#### **AUTODOC** recommends:

 Replacement: brake pads – BMW 8 (E31). After applying the spray, wait a few minutes.

27

Install the wheel.



#### AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW 8 (E31)

CLUB.AUTODOC.CO.UK 10-13