







i Important!

This replacement procedure can be used for: BMW 3 Saloon (E46) 320d 2.0, BMW 3 Touring (E46) 320d 2.0, BMW 3 Saloon (E46) 318d 2.0, BMW 3 Touring (E46) 318d 2.0

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–13





REPLACEMENT: COOLANT HOSE – BMW E46 TOURING. TOOLS YOU NEED:



- All-purpose cleaning spray
- Drive socket # 12
- HEX bit No.H5
- Ratchet wrench
- Flat screwdriver

- Funnel
- Fluid container
- Crow bar
- Fender cover
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-13





Replacement: coolant hose – BMW E46 Touring. AUTODOC recommends:

- Check the cooling circuit for leaks. Replace any worn parts.
- All work should be done with the engine stopped.

REPLACEMENT: COOLANT HOSE – BMW E46 TOURING. TAKE THE FOLLOWING STEPS:

Open the bonnet.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.




Unscrew the fasteners of the air distribution housing assembly. Use a drive socket #12. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 3-13









- Secure the wheels with chocks.
- Lift the car using a jack or place it over an inspection pit.



Unscrew the engine cover fastener. Use HEX No.H5. Use a ratchet wrench.



Remove the engine cover.



AUTODOC recommends:

• Do not apply excessive force when removing the part. Otherwise you may damage it.

CLUB.AUTODOC.CO.UK 4–13





9 Prepare a container for fluids.



Unscrew the coolant drain plug. Use a flat screwdriver.



Drain the coolant from the engine.



Replacement: coolant hose – BMW E46 Touring. Tip:

- Caution! The coolant can be very hot.
- Wear gloves to prevent contact with hot liquid.
- All work should be done with the engine stopped.
- Wait until the coolant has completely flowed out of the drain hole.

CLUB.AUTODOC.CO.UK 5-13







12 Unscrew the coolant reservoir cap.



Remove the coolant hose retainers. Use a crowbar.



Detach the coolant hose. Use a crowbar.



Replacement: coolant hose – BMW E46 Touring. Tip from AUTODOC experts:

- Be careful! The coolant may leak.
- Replacement: coolant hose BMW E46 Touring. To avoid damaging the part when removing it, do not use excessive force.

CLUB.AUTODOC.CO.UK 6-13







Screw in the coolant drain plug. Use a flat screwdriver.



Clean the mounting seats of the coolant hose. Use all-purpose cleaning spray.



Connect the new coolant hose.



Fasten the retainers of the coolant hose.



19 Insert the funnel.



CLUB.AUTODOC.CO.UK 7-13







20

Pour coolant in the coolant reservoir.



Replacement: coolant hose – BMW E46 Touring. Professionals recommend:

- Only use the coolant recommended by the manufacturer.
- The coolant level should be at the MAX mark.
- Wait until the air goes out of the system.

21

Unscrew the bleeder screws. Use a flat screwdriver.



Please note!

• This is necessary to remove any remaining air from the system.


CLUB.AUTODOC.CO.UK 8-13







Screw in the bleeder screws. Use a flat screwdriver.



Check the coolant level. If necessary, top up to the required level.



Screw on the coolant reservoir cap.



Install the engine cover and secure it.

25



AUTODOC recommends:

 Replacement: coolant hose – BMW E46 Touring. To avoid damaging the part during installation, do not use excessive force.

CLUB.AUTODOC.CO.UK 9-13







Screw in the engine cover fasteners. Use HEX No.H5. Use a ratchet wrench.



Reinstall the air distribution housing assembly.



Screw in the fasteners of the air distribution housing assembly. Use a drive socket #12. Use a ratchet wrench.



Lower the car.

30



Remove the jacks and chocks.

CLUB.AUTODOC.CO.UK 10-13