

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, BMW 1

Hatchback (E81) 130i 3.0, BMW 1 Hatchback (E81) 118i 2.0, BMW 1 Hatchback (E81)

120i 2.0, BMW 1 Hatchback (E81) 118d 2.0, BMW 1 Hatchback (E81) 123d 2.0, BMW

1 Hatchback (E81) 116i 2.0, BMW 1 Hatchback (E81) 116d 2.0


The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E90) 318i 2.0

CLUB.AUTODOC.CO.UK 1–11



REPLACEMENT: FRONT LOWER ARM – BMW 1 HATCHBACK (E81). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Combination spanner #21
- Torx bit T30

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Hammer
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-11





Replacement: front lower arm – BMW 1 Hatchback (E81). AUTODOC recommends:

- The replacement procedure is identical for the left and right lower control arms.
- Please note: all work on the car BMW 1 Hatchback (E81) should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the front of the car and secure on supports.
- 4 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3-11





AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW 1 Hatchback (E81)

Remove the wheel.

8



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



Unscrew the fastener connecting the ball joint of the front control arm to the steering knuckle. Use a combination spanner #21. Use Torx T30. Use a ratchet wrench.



Clean the fasteners connecting the control arm to the subframe. Use a wire brush. Use WD-40 spray.

CLUB.AUTODOC.CO.UK 4-11








Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces).



- Remove the rear fastener of the control arm. Use a hammer.
- Disconnect the lower arm from the steering knuckle. Use a hammer.



Remove the arm.

13



Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 5-11







14 Install a new arm.



Replacement: front lower arm – BMW 1 Hatchback (E81). Professionals recommend:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.
- Connect the lower arm to the steering knuckle.
- Screw in the fastener connecting the ball joint of the front control arm to the steering knuckle. Use a combination spanner #21. Use Torx T30. Use a torque wrench. Tighten it to 165 Nm torque.



Treat the fasteners of the ball joint. Use copper grease.



Install the rear fastener of the control arm.

18

CLUB.AUTODOC.CO.UK 6-11





Screw the rear fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces).



20 Prop up the steering knuckle. Use a hydraulic transmission jack.



Tighten the rear fastener of the control arm. Use a combination spanner #18 (2 pieces). Use a torque wrench. Tighten it to 68 Nm torque.+90°



AUTODOC recommends:

• Important! Be sure to use new fasteners.

Treat all joints of the arm. Use copper grease.



CLUB.AUTODOC.CO.UK 7-11







Remove the support from under the steering knuckle.



AUTODOC recommends:

 Replacement: front lower arm – BMW 1 Hatchback (E81). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.





Clean the brake disk surface. Use a brake cleaner.

25



AUTODOC recommends:

 Replacement: front lower arm – BMW 1 Hatchback (E81). After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 8-11







26 Install the wheel.

28



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. BMW 1 Hatchback (E81)
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



CLUB.AUTODOC.CO.UK 9-11







29

Remove the jacks and chocks.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-11