





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: BMW X5 (E70) xDrive 30 d, BMW X5 (E70) xDrive 40 d, BMW X5 (E70) 3.0 d, BMW X5 (E70) 3.0 sd, BMW X5 (E70) xDrive 35 d

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW X5 (E53) 4.4 i

CLUB.AUTODOC.CO.UK 1–15







REPLACEMENT: SHOCK ABSORBERS – BMW X5 (E70). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #19
- Combination spanner #21
- Drive socket # 10
- Drive socket # 21

- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Adjustable wrench
- Crow bar
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-15







Replacement: shock absorbers – BMW X5 (E70). AUTODOC recommends:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – BMW X5 (E70). USE THE FOLLOWING PROCEDURE:

1 5

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-15







4 Unscrew the wheel bolts.



Replacement: shock absorbers – BMW X5 (E70). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



- 6 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the lower fastener of the shock absorber. Use a combination spanner #21. Use a drive socket #21. Use a ratchet wrench.



Remove the fastening bolt.

CLUB.AUTODOC.CO.UK 4-15







9 Support the stub axle. Use a hydraulic transmission jack.



Detach the lower part of the shock absorber. Use a crowbar.



Remove the support from under the stub axle.



AUTODOC recommends:

- BMW X5 (E70) Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.
- Lower the car.
- Open the boot lid.

CLUB.AUTODOC.CO.UK 5-15







Remove the boot front lower lining.



Unscrew fixing bolts of the protective cover. Use a drive socket #10. Use a ratchet wrench.



Remove the cover of the boot side lining.



- Fold down the backrests of the rear seats.
 - 18 Remove the protective cover.



CLUB.AUTODOC.CO.UK 6-15







Remove the clips. Use a flat screwdriver.



Remove the protective cover.



Remove the protective cap of the shock absorber mount. Use a flat screwdriver.



- Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.
- Remove the shock absorber piston rod fastening. Use a combination spanner #19. Use an adjustable wrench.



CLUB.AUTODOC.CO.UK 7–15







AUTODOC recommends:

• To avoid injuries, hold the shock absorber when undoing the fastening bolts.

24

Remove the shock absorber.



Remove the shock absorber dust cap and the bump stop. Use a flat screwdriver.



Replacement: shock absorbers – BMW X5 (E70). Tip from AUTODOC experts:

- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.

CLUB.AUTODOC.CO.UK 8-15







Install the dust sleeve and the bump stop on the new shock absorber.



Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



Place the shock absorber in the wheel arch and secure it.



28

Replacement: shock absorbers – BMW X5 (E70). AUTODOC experts recommend:

• To avoid injury, hold the shock absorber cautiously tight when screwing in the fastening bolts.

CLUB.AUTODOC.CO.UK 9-15







Tighten the shock absorber rod nut. Use a combination spanner #19. Use an adjustable wrench. Use a torque wrench. Tighten it to 25 Nm torque.



- Treat the shock absorber fasteners. Use copper grease.
- Install the protective shock absorber mounting cap.



Install the protective cover.

33



Reinstall the pop clips of the protective cover.



Return the seat to its original position.

CLUB.AUTODOC.CO.UK 10-15