





### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### i Important!

This replacement procedure can be used for: BMW 6 Coupe (E63) 645Ci 4.4, BMW 6 Coupe (E63) 630i 3.0, BMW 6 Coupe (E63) 650i 4.8, BMW 6 Coupe (E63) M, BMW 6 Coupe (E63) 635d 3.0, BMW 6 Coupe (E63) 630i 3.0 (N52B30A, N52B30B, N52B30BF)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E60) 525d 2.5

CLUB.AUTODOC.CO.UK 1–10







## REPLACEMENT: ANTI ROLL BAR LINKS – BMW 6 COUPE (E63). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #15
- Combination spanner #16
- Combination spanner #17
- Combination spanner #18

- Drive socket # 15
- Drive socket # 16
- HEX bit no.H6.
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-10







### Replacement: anti roll bar links – BMW 6 Coupe (E63). AUTODOC experts recommend:

- Replace the stabiliser links on BMW 6 Coupe (E63) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: ANTI ROLL BAR LINKS – BMW 6 COUPE (E63). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the w

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-10







4 Unscrew the wheel bolts.



### **AUTODOC** recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. BMW 6 Coupe (E63)

Remove the wheel.

6



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 4-10







Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #15. Use a combination spanner #16.



Unscrew the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #18. Use HEX No.H6. Use a ratchet wrench.



g Remove the stabilizer rod.



Replacement: anti roll bar links – BMW 6 Coupe (E63). Tip from AUTODOC experts:

• Examine stabiliser bushes. Replace them if needed.

CLUB.AUTODOC.CO.UK 5-10







Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.



11 Install the transverse stabilizer link.



Tighten the stabiliser link fastener. Use a combination spanner #15. Use a combination spanner #17. Use a combination spanner #18. Use HEX No.H6. Use a ratchet wrench.



Tighten the fastener connecting the stabilizer bar with the control arm. Use a drive socket #18. Use a torque wrench. Tighten it to 100 Nm torque.



CLUB.AUTODOC.CO.UK 6-10







Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #16. Use a torque wrench. Tighten it to 65 Nm torque.



Treat all joints of the stabiliser link. Use copper grease.



Clean the wheel rim mounting seat. Use a wire brush. Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.

17



CLUB.AUTODOC.CO.UK 7–10







#### AUTODOC recommends:

 Replacement: anti roll bar links – BMW 6 Coupe (E63). After applying the spray, wait a few minutes.

18

Install the wheel.



Replacement: anti roll bar links – BMW 6 Coupe (E63). AUTODOC experts recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



CLUB.AUTODOC.CO.UK 8-10







21

Remove the jacks and chocks.







CLUB.AUTODOC.CO.UK 9-10