





This video shows the replacement procedure of a similar car part on another vehicle

#### (i) Important!

This replacement procedure can be used for:

BMW 3 Coupe (E92) 318i 2.0, BMW 3 Coupe (E92) 335i 3.0, BMW 3 Coupe (E92) 335d 3.0, BMW 3 Coupe (E92) 320i 2.0, BMW 3 Coupe (E92) M, BMW 3 Coupe (E92) 325i 3.0, BMW 3 Coupe (E92) 330d 3.0, BMW 3 Coupe (E92) 328i 3.0, BMW 3 Coupe (E92) 330i xDrive 3.0, BMW 3 Coupe (E92) 335i xDrive 3.0, BMW 3 Coupe (E92) 330d xDrive 3.0, BMW 3 Coupe (E92) 320d xDrive 2.0, BMW 3 Coupe (E92) 320d 2.0, BMW 3 Coupe (E92) 325d 3.0, BMW 3 Coupe (E92) 325i 2.5, (+7)


The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 1 Coupe (E82) 125i 3.0

CLUB.AUTODOC.CO.UK 1-6







Plastic trim tool

Fender cover

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-6





## Replacement: glass for wing mirror – BMW 3 Coupe (E92). Professionals recommend:

- The replacement procedure is identical for the right and left side mirror glass.
- All work should be done with the engine stopped.

# REPLACEMENT: GLASS FOR WING MIRROR – BMW 3 COUPE (E92). RECOMMENDED SEQUENCE OF STEPS:

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



7 Tilt the mirror glass out of the housing.



Carefully release the mirror glass from its attachment. Use a plastic trim tool.



CLUB.AUTODOC.CO.UK 3-6







4 Remove the mirror glass.



#### AUTODOC recommends:

- Replacement: glass for wing mirror BMW 3 Coupe (E92). Do not use excessive force when removing the part as this may damage it.
- 5 Detach the mirror heating connectors.



6 Attach the mirror heating connectors.



Install the new mirror glass. Make sure you hear a click indicating that it is locked in place.



CLUB.AUTODOC.CO.UK 4-6



### O

## Replacement: glass for wing mirror – BMW 3 Coupe (E92). AUTODOC recommends:

- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.
- Make sure the mirror glass is positioned correctly. It should be aligned with the locking tabs on the housing.
- 8 Clean the mirror glass.
- Remove the fender protection cover.



Switch on the ignition. This is necessary in order to make sure that the component operates properly.



11 Switch off the ignition.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 5-6