









important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 1 Coupe (E82) M, BMW 3 Touring (E91) 318i 2.0, BMW 3 Touring (E91) 316d 2.0, BMW 3 Saloon (E90) 320d xDrive 2.0, BMW 1 Coupe (E82) 118d 2.0, BMW 3 Coupe (E92) 318i 2.0, BMW 3 Convertible (E93) 318i 2.0, BMW 3 Convertible (E93) 325d 3.0, BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, (+ 114)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-10







REPLACEMENT: ANTI ROLL BAR LINKS – BMW E90. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Drive socket # 13
- Combination spanner #17

- HEX bit No.H5.
- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Torque wrench
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-10







AUTODOC recommends:

- Replace the stabiliser links on BMW E90 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car BMW E90 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-10







Unscrew the wheel bolts.

4



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW E90
- Remove the wheel.



- 6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use HEX No.H5. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4–10







Unscrew the fastener connecting the stabilizer link to the control arm. Use a drive socket #13. Use a ratchet wrench. Use a flat screwdriver.



- 9 Remove the fastening bolt.
- Remove the stabilizer rod.

11



Replacement: anti roll bar links – BMW E90. Tip from AUTODOC:

- Examine stabiliser bushes. Replace them if needed.
- Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 5-10







12 Install the transverse stabilizer link.



install the rod fastening to the stabilizer and tighten it. Use a drive socket #13. Use a torque wrench. Tighten it to 21 Nm torque.



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17 (2 pieces). Use a torque wrench. Tighten it to 58 Nm torque.



- Treat all joints of the stabiliser link. Use copper grease.
- Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



CLUB.AUTODOC.CO.UK 6-10







17 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

• Replacement: anti roll bar links – BMW E90. After applying the spray, wait a few minutes.

18 Ir

Install the wheel.



AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E90

19

Screw in the wheel bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 7–10







Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



Remove the jacks and chocks.





VIEW MORE TUTORIALS


CLUB.AUTODOC.CO.UK 8-10







AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

ANTI ROLL BAR LINKS: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 9-10