





### **VIDEO TUTORIAL**



### (i) Important!

This replacement procedure can be used for:

BMW 3 Saloon (E46) 318i 1.9, BMW 3 Saloon (E46) 328i 2.8, BMW 3 Saloon (E46) 320d 2.0, BMW 3 Saloon (E46) 323i 2.5, BMW 3 Saloon (E46) 320i 2.0, BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Saloon (E46) 316i 1.9, BMW 3 Touring (E46) 320i 2.0, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Coupe (E46) 318ci 1.9, BMW 3 Touring (E46) 318i 1.9, BMW 3 Touring (E46) 328i 2.8, BMW 3 Touring (E46) 320d 2.0, BMW 3 Saloon (E46) 330d 2.9, (+43)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–18







# REPLACEMENT: FRONT LOWER ARM – BMW E46 CONVERTIBLE. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #18
- Combination spanner #19
- Combination spanner #21
- Drive socket # 13
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench

- Torque wrench
- Ball joint puller
- 3-Arm Gear Puller
- Phillips screwdriver
- Crow bar
- Rubber mallet
- Vice
- Hydraulic transmission jack
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-18







## Replacement: front lower arm – BMW E46 convertible. Professionals recommend:

- The replacement procedure is identical for the left and right lower control arms.
- Replacement of the independent suspension lower arm in some cars requires a part of the outlet piping of the additional heater to be removed.
- All work should be done with the engine stopped.

# REPLACEMENT: FRONT LOWER ARM – BMW E46 CONVERTIBLE. RECOMMENDED SEQUENCE OF STEPS:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-18







Raise the front of the car and secure on supports.



Unscrew the wheel bolts.



#### **AUTODOC** recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. BMW E46 convertible
- Remove the wheel.



Unscrew the fasteners of the lower sound insulation. Use a Phillips screwdriver.



CLUB.AUTODOC.CO.UK 4-18







Remove the lower sound insulation.



### Please note!

• Some cars are not equipped with the lower sound insulation.

8

Clean all joints of the arm. Use a wire brush. Treat all joints of the arm. Use WD-40 spray.



## Replacement: front lower arm – BMW E46 convertible. Tip:

- After applying the spray, wait a few minutes.
- Wear protective goggles.

CLUB.AUTODOC.CO.UK 5-18







2 Loosen the fastener connecting the ball joint to the steering knuckle. Use a combination spanner #19.



Detach the fastener connecting the suspension level sensor to the suspension control arm. Use a drive socket #13. Use a ratchet wrench.



Unscrew the arm fastening from the subframe. Use a combination spanner #21.



12

Unscrew the rear arm fastening. Use a drive socket #18. Use a combination spanner #18. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 6-18







Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #19.



Disconnect the ball joint from the steering knuckle. Use a ball joint puller.



Disconnect the lower arm from the steering knuckle.



Prop up the steering knuckle. Use a hydraulic transmission jack.



17 Remove the arm. Use a crowbar.



CLUB.AUTODOC.CO.UK 7-18







Grip the suspension control arm in a vice.



Treat the control arm bush. Use WD-40 spray.



Remove the control arm bush. Use 3-Arm Gear Puller.



Loosen the vice and remove the control arm.



Grip the new control arm in a vice.

22



CLUB.AUTODOC.CO.UK 8-18







Treat the mounting seat of the control arm bush. Use WD-40 spray.



Install the control arm bush to its mounting seat. Use a rubber mallet.



Loosen the vice and remove the control arm.

26



Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 9-18







27 Install a new arm.



Replacement: front lower arm – BMW E46 convertible. Tip from AUTODOC experts:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.

28 Install the control arm fasteners.

29



Screw the fastener connecting the control arm to the subframe. Use a combination spanner #21.



CLUB.AUTODOC.CO.UK 10-18