






### **VIDEO TUTORIAL**



# (i) Important!

This replacement procedure can be used for:

BMW 3 Saloon (E46) 318i 1.9, BMW 3 Saloon (E46) 328i 2.8, BMW 3 Saloon (E46) 320d 2.0, BMW 3 Saloon (E46) 323i 2.5, BMW 3 Saloon (E46) 320i 2.0, BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Saloon (E46) 316i 1.9, BMW 3 Touring (E46) 320i 2.0, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Coupe (E46) 318i 1.9, BMW 3 Touring (E46) 328i 2.8, BMW 3 Touring (E46) 320d 2.0, BMW 3 Saloon (E46) 330d 2.9, (+ 52)

The steps may slightly vary depending on the car design.


CLUB.AUTODOC.CO.UK 1–13







# REPLACEMENT: BRAKE HOSE – BMW E46 TOURING. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #9
- Combination spanner #10
- Combination spanner #14

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Brake bleeder kit
- Fluid container
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-13







### Replacement: brake hose – BMW E46 touring. AUTODOC recommends:

- The replacement procedure is identical for the right and left brake hoses on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: BRAKE HOSE – BMW E46 TOURING. TAKE THE FOLLOWING STEPS:

Open the bonnet. Unscrew the brake fluid reservoir cap.



Secure the wheels with chocks.

3



Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-13







A Raise the front of the car and secure on supports.



5 Unscrew the wheel bolts.



#### **AUTODOC** recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. BMW E46 touring
- Remove the wheel.

7.1



Clean the area where the brake hose is connected to the brake caliper and to the brake circuit pipe.



CLUB.AUTODOC.CO.UK 4–13







7.2 Use a wire brush. Use WD-40 spray.



Put a container for gathering brake fluid beneath.



Unscrew the fastener connecting the brake hose to the brake circuit pipe. Use a combination spanner #10.



Detach the brake hose from the shock strut.



Loosen the brake hose fastening. Use a combination spanner #14.



CLUB.AUTODOC.CO.UK 5-13







Unscrew the brake hose from the brake caliper.



Screw the new brake hose onto the brake caliper.



Tighten the fastener connecting the brake pipe to the brake caliper. Use a combination spanner #14. Use a torque wrench. Tighten it to 22 Nm torque.



Clean the brake hose mounting seat on the brake circuit pipe. Use a brake cleaner.



15

Replacement: brake hose – BMW E46 touring. AUTODOC experts recommend:

After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 6-13







Tighten the fastener connecting the brake hose to the brake circuit pipe. Use a combination spanner #10. Use a torque wrench. Tighten it to 14 Nm torque.



Clean the area where the brake hose is connected to the brake caliper and to the brake circuit pipe. Use a brake cleaner.



## AUTODOC recommends:

 Replacement: brake hose – BMW E46 touring. After applying the spray, wait a few minutes.

18

Fasten the brake hose on the strut.



CLUB.AUTODOC.CO.UK 7–13







Connect the brake bleeder kit to the brake bleeder screw.



Undo the brake bleeder screw. Use a combination spanner #9.



Press the brake pedal several times to remove any air from the system.



Tighten the brake bleeder screw. Use a combination spanner #9.



Disconnect the brake bleeder kit.



CLUB.AUTODOC.CO.UK 8-13







Clean dirt from the brake hose bolt. Use a brake cleaner.



## Replacement: brake hose – BMW E46 touring. Tip:

- After applying the spray, wait a few minutes.
- Clean the brake disk surface. Use a wire brush. Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



26 Install the wheel.



### AUTODOC recommends:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

CLUB.AUTODOC.CO.UK 9-13







Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.



Remove the jacks and chocks.

30



Check the brake fluid level in the expansion tank and refill if necessary.



CLUB.AUTODOC.CO.UK 10-13