





#### **VIDEO TUTORIAL**



### i Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 5 Saloon (E39) 520i 2.0, BMW 5 Saloon (E39) 525tds 2.5, BMW 5 Saloon (E39) 523i 2.5, BMW 5 Saloon (E39) 528i 2.8, BMW 3 Saloon (E90) 318d 2.0, BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 5 Saloon (E39) 525td 2.5, BMW 3 Saloon (E46) 318i 1.9, BMW 3 Saloon (E46) 328i 2.8, BMW 3 Saloon (E46) 320d 2.0, BMW 5 Touring (E39) 528i 2.8, BMW 3 Saloon (E46) 323i 2.5, (+ 254)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–21







# REPLACEMENT: STRUT MOUNT – BMW X3 E83. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #16
- Drive socket # 13
- Drive socket #16
- Drive socket # 18
- Drive socket # 19

- Drive socket # 21
- HEX bit No.H6
- Shock absorber socket
- Wheel impact socket #17
- Ratchet wrench
- Crow bar
- Hydraulic strut spring compressor
- Hydraulic transmission jack
- Fender cover
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-21







## Replacement: strut mount – BMW X3 E83. AUTODOC experts recommend:

- The replacement procedure is identical for the mounts of the left and right shock struts of the front suspension.
- All mounts of the front shock struts should be replaced simultaneously.
- Please note: all work on the car BMW X3 E83 should be done with the engine switched off.

#### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the bonnet.



2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



CLUB.AUTODOC.CO.UK 3-21







Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.



Loosen the upper fasteners of the suspension strut. Use a drive socket #13. Use a ratchet wrench.



- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.



CLUB.AUTODOC.CO.UK 4-21







8 Unscrew the wheel bolts.



#### AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW X3 E83

9 Remove the wheel.



Disconnect the brake hose.

11



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 5-21







Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #16. Use a ratchet wrench.



13 Remove the stabilizer rod.



Disconnect the ABS sensor wiring.



- Clean the lower fastener connecting the suspension strut to the steering knuckle. Use a wire brush. Use WD-40 spray.
- Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 6-21







17 Remove the fastening bolt.



Prop up the steering knuckle. Use a hydraulic transmission jack.



Release the lower fastener connecting the shock strut to the steering knuckle. Use a special drive socket to remove the shock absorber. Use a ratchet wrench.



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



20

#### **AUTODOC** recommends:

 Replacement: strut mount – BMW X3 E83. After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 7-21







Unscrew the fastener connecting the control arm to the subframe. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



- Lower the hydraulic transmission jack by 10-15 cm.
- Disconnect the steering knuckle from the shock absorber strut.



Unscrew the upper fasteners of the shock strut.

#### AUTODOC recommends:

- BMW X3 E83 To avoid injury, hold the suspension strut while unscrewing the fastening bolts.
- Remove the suspension strut.



CLUB.AUTODOC.CO.UK 8-21







Set the shock absorber strut on the spring compressor tool.



## Replacement: strut mount – BMW X3 E83. Professionals recommend:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

Compress the spring.

28

26



Remove the shock strut mount cap. Use a crowbar.



CLUB.AUTODOC.CO.UK 9-21







Treat the shock strut rod. Use a wire brush. Use WD-40 spray.



Remove the strut piston rod nut. Use a drive socket #21. Use HEX No.H6. Use a ratchet wrench.



Remove the top strut mount.



#### Replacement: strut mount – BMW X3 E83. AUTODOC recommends:

• Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

CLUB.AUTODOC.CO.UK 10-21