









# (i) Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 3 Touring (E91) 318i 2.0, BMW 3 Touring (E91) 316d 2.0, BMW 1 Coupe (E82) 118d 2.0, BMW 3 Coupe (E92) 318i 2.0, BMW 3 Convertible (E93) 318i 2.0, BMW 3 Convertible (E93) 325d 3.0, BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Saloon (E90) 320d 2.0, (+ 67)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–17







# REPLACEMENT: SHOCK ABSORBERS – BMW E90. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #16
- Drive socket # 16
- Drive socket # 17
- Torx bit T25

- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Phillips screwdriver
- Adjustable wrench
- Crow bar
- Hydraulic transmission jack
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-17







### Replacement: shock absorbers – BMW E90. Tip from AUTODOC:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car BMW E90 should be done with the engine switched off.

## CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-17







4 Unscrew the wheel bolts.



## AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
  BMW E90
- Remove the wheel.



Support the stub axle. Use a hydraulic transmission jack.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.

CLUB.AUTODOC.CO.UK 4-17







Unscrew the lower fastener of the shock absorber. Use a drive socket #17. Use a ratchet wrench.



- 9 Remove the fastening bolt.
- 10 Remove the support from under the stub axle.



#### **AUTODOC** recommends:

- BMW E90 Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.
- Detach the lower part of the shock absorber. Use a crowbar.



CLUB.AUTODOC.CO.UK 5-17







Lower the car.



Open the boot lid.

16



Remove the boot front lower lining.



Remove the clips from the plastic boot sill guard. Use flat screwdrivers (2 pieces).



Unscrew the fasteners of the plastic boot sill guard. Use a Phillips screwdriver.



CLUB.AUTODOC.CO.UK 6-17







17 Remove the plastic door sill plate.



18 Remove the cover of the boot side lining.



Remove the clips of the boot side lining. Use a flat screwdriver.



Unscrew the fastener of the boot side lining. Use Torx T25. Use a ratchet wrench.



Remove the boot side lining.



CLUB.AUTODOC.CO.UK 7-17







Remove the protective cap of the shock absorber mount. Use a flat screwdriver.



- Clean the fasteners of the shock absorber upper mount. Use a wire brush. Use WD-40 spray.
- Unscrew the upper fastener of the shock absorber. Use a combination spanner #16. Use an adjustable wrench.



#### **AUTODOC** recommends:

- Important! Hold the shock absorber while unscrewing the fastening bolts. BMW E90
- Remove the shock absorber.



Remove the shock absorber upper mount.

CLUB.AUTODOC.CO.UK 8-17







Remove the shock absorber dust cap and the bump stop.



#### AUTODOC recommends:

- Replacement: shock absorbers BMW E90. Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.
- Install the dust sleeve and the bump stop on the new shock absorber.



- Install the shock absorber upper mount.
- Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 9-17







Place the shock absorber in the wheel arch and secure it.



31

#### AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. BMW E90
- Tighten the top shock absorber fastening. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 27 Nm torque.



- Treat the shock absorber fasteners. Use copper grease.
- Install the protective shock absorber mounting cap.



CLUB.AUTODOC.CO.UK 10-17