


SUDOKU

RSTG
Correct
D59
Wrong
D60
R76
R77
S29
S30
S31
S32
Level
D56 1
D57 2
D58 3
Change
S33
How to play
Select a difficulty level, then press "NEW".
Normal Sudoku rules: fill each row, column, square with numbers 1-9.
To write to the board, press a row/column/digit sequentially, in any order. To erase, be sure to press the "CLEAR" button.
When you're ready to submit your solution, press the "GUESS" button.
If your solution is correct, the green LED will light up, otherwise the red LED will.
Press "RESET" to start again, or "END" to reveal the solution.
Have fun!

CHECK
NEWG
WRONG
YES
GND VCC
EASY MED HARD
LVLSET GIVEUP
KEY0 KEY1 COLON
KEY2 KEY3 KEY4
KEY5 KEY6 DIGON
KEY7 ROWON
KEY8 KEY9
COL0 COL1 COL2
COL3 COL4 COL5
COL6 COL7 COL8

Column select




Sudoku v1.0
08/10/2021

Row select





Digit select



SUDOKU

Sudoku v1.0
08/08/2021





SUDOKU

Sudoku v1.0
08/10/2021

