

Compass Calibration



NOTE: *This procedure only applies to vehicles that have a compass zone or compass calibration adjustment menu available. If the compass zone/calibration menu is not available, the compass data is provided by the **GPSM** and no compass zone or compass calibration is required.*

1. **NOTE:** *For optimum calibration, drive to an open, level location away from large metallic objects or structures such as bridges, steel buildings, etc. Switch off all non-essential electrical accessories (heated rear window, heater fan, A/C, map lamps, and wipers) and make sure all doors are closed.*

Start the vehicle.

2. **NOTE:** *The vehicle remains in the CAL mode until the compass has been successfully calibrated.*

NOTE: *While holding the Front Controls Interface Module (FCIM) 7 and 9 buttons down, the compass display first enters the ZONE setting mode (after 5 seconds) and then after another 5 seconds (approximately 10 seconds total), the compass display enters the CAL mode.*

Press and hold (for approximately 10 seconds) the 7 and 9 buttons until the CAL indicator appears in the display, then release the buttons.

3. **NOTE:** *If the CAL indicator does not turn off after the vehicle is driven in a circle at least 5 times, repeat the procedure.*

Drive the vehicle slowly at less than 5 km/h (3 mph) in a continuous circle until the CAL indicator disappears from the display and the compass heading is shown.

4. If the CAL indicator does not turn off after driving in a circle at least 5 times (and the procedure has been repeated at least once), install a new compass.

For vehicles equipped an auto-dimming interior rear view mirror, install a new mirror. Refer to Section 501-09.

For vehicles without an auto-dimming interior rear view mirror, install a new compass module. Refer to the appropriate section in Group 415 for the procedure.