


Parking Aid Module (PAM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Parking Aid Module (PAM) nuts (2 required)
2	157850 157850	PAM and parking aid speaker assembly
3	—	PAM electrical connector (part of 14A005)

Removal and Installation

1. Disconnect the PAM electrical connector.
2. Remove the 2 PAM nuts.
3. Remove the PAM .
4. To install, reverse the removal procedure.