

Satellite Radio Electronic Serial Number (ESN) Retrieval



NOTE: *If the ~~SDARS~~ , Audio Front Control Module (ACM) , ~~FCIM~~ (if equipped), or ~~EDIM~~ (if equipped) are inoperative (blank or do not power on), obtain the Electronic Serial Number (ESN) by referencing the label attached to the Audio Front Control Module (ACM) chassis.*

1. Turn the Audio Front Control Module (ACM) on.
2. Operate the audio system in satellite radio mode.
3. Depending on vehicle configuration, simultaneously press and hold the AUX button and preset button 1, or the SIRIUS button and preset button 1.
 - The Satellite Digital Audio Receiver System (SDARS) module Electronic Serial Number (ESN) displays on the ~~EDIM~~ .
4. Record the ~~SDARS~~ module ~~ESN~~ .