


Accessory Protocol Interface Module (APIM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	W704875 W704875 -S-S	Accessory Protocol Interface Module (APIM) screw
2	—	APIM electrical connector (part of 14401)
3	—	Universal Serial Bus (USB) cable (part of 14D202)
4	14D212 14D212	APIM

Removal and Installation

1. Remove the instrument panel upper bin.

1. Remove the rubber mat.

2. Remove the 2 screws.

3. Remove the instrument panel upper bin.
2. Remove the APIM screw and position the APIM upward.
3. Remove the APIM .

• Disconnect the electrical connector and the Universal Serial Bus (USB) cable.
4. To install, reverse the removal procedure.

• If a new APIM is being installed, program the APIM . For additional information, refer to Accessory Protocol Interface Module (APIM) Programming.