


Front Controls Interface Module (FCIM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Front Controls Interface Module (FCIM) screws (12 required) (part of 18842)
2	18842 18842	FCIM

Removal and Installation

1. Remove the instrument panel finish panel - center lower. For additional information, refer to Section 501-12.
2. Remove the 12 screws and the Front Controls Interface Module (FCIM) .
3. To install, reverse the removal procedure.