


Speaker — A-Pillar

 [Ford Ecat Electronic Parts Catalog](#)

NOTE: LH shown, RH similar.



Item	Part Number	Description
1	W701678 W701678 -S-S	A-pillar speaker screws (2 required)
2	18978 18978	A-pillar speaker

Removal and Installation

1. Remove the A-pillar trim panel. For additional information, refer to Section 501-05.
2. Remove the 2 screws and the A-pillar speaker.
3. To install, reverse the removal procedure.