


Universal Serial Bus (USB) Cable and Port

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	14D202 14D202	Universal Serial Bus (USB) cable and port

Removal and Installation

1. Remove the Accessory Protocol Interface Module (APIM) . For additional information, refer to Accessory Protocol Interface Module (APIM) in this section.
2. Remove the Audio Front Control Module (ACM) . For additional information, refer to Audio Control Module (ACM) in this section.
3. Release the pushpins and remove the Universal Serial Bus (USB) cable and port.
4. To install, reverse the removal procedure.