

Audio Input Jack


 [Ford Ecat Electronic Parts Catalog](#)

Removal and Installation

1.



2. Remove the audio input jack bezel by prying rearward.
- Disconnect the electrical connector.
 - Release the tabs and remove the audio input jack.



3. To install, reverse the removal procedure.