


Global Positioning System Module (GPSM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	W707628 W707628 -S-S	Global Positioning System Module (GPSM) screw
2	—	GPSM electrical connector (part of 14401)
3	10E893 10E893	GPSM

Removal and Installation

1. Remove the upper storage compartment. For additional information, refer to Section 501-12.
2. Remove the screw and the Global Positioning System Module (GPSM) .
 - Disconnect the electrical connector.
3. To install, reverse the removal procedure.