

Speaker Audio Test



Speaker Audio Test

1. Download the diagnostic sound tracks to a suitable USB drive and install the USB drive in the Media Hub.

NOTE: To download the file, right click on the link and select "Save target as..." then save the file on the USB drive.

- [125Hz Test](#)
- [100Hz Test](#)
- [80Hz Test](#)
- [63Hz Test](#)
- [50Hz Test](#)
- [40Hz Test](#)