


Ballast


 [Ford Ecat Electronic Parts Catalog](#)

Removal and Installation

- 1. Remove the headlamp assembly. Refer to Headlamp Assembly.
- 2.



- 3.



N0148167

4. To install, reverse the removal procedure.