


Headlamp Switch

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	1504481 1504481	LH instrument panel side finish panel
2	11654 11654	Headlamp switch
3	—	Headlamp switch electrical connector (part of 14401)

Removal and Installation

1. Remove the instrument panel side finish panel.
2. **NOTE:** *The 3 retaining tabs on the headlamp switch are located at approximately 3, 6 and 11 o'clock positions when viewed from the front.*

Reaching from behind, release the 3 tabs and push the headlamp switch through the opening.
 - Disconnect the electrical connector.
3. To install, reverse the removal procedure.