


Stoplamp Switch

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Stoplamp switch electrical connector (part of 12A581)
2	13480 13480	Stoplamp switch

Removal and Installation

NOTICE: Do not press or pull on the brake pedal when installing or removing the stoplamp switch, otherwise misadjustment or damage to the stoplamp switch can occur.

1. Disconnect the stoplamp switch electrical connector.
2. Rotate the stoplamp switch clockwise approximately one-eighth turn and remove it.
3. To install, reverse the removal procedure.