


Ambient Lighting Switch

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	045A76045A76	Floor console upper finish panel
2	—	Ambient lighting switch electrical connector (part of harness 14E078)
3	13D80613D806	Ambient lighting switch

Removal and Installation

1. Remove the floor console upper finish panel.
 - Lift the floor console finish panel upward to release the retaining clips
2. Disconnect the electrical connector.
3. Release the tabs and remove the ambient lighting switch.
4. To install, reverse the removal procedure.