

Fender Moulding — Rear



Removal and Installation

Standard

1. Remove the 2 rear fender moulding screws.
2. Remove the 4 rear fender moulding pin-type retainers.
3. Starting at the front of the fender moulding, pull outward to release it from the fender.

SVT Raptor

4. Remove the 6 rear fender moulding pin-type retainers.
5. Remove the rear fender moulding screws.
6. **NOTICE: Pry directly on the pin-type retainer. Do not pry on the fender moulding. Failure to follow this direction may result in damage to the component.**

Using a non-marring tool, starting at the front of the rear fender moulding, pry outward on the pin-type retainers by pushing the handle toward the fender.

7. Remove the rear fender moulding.

All vehicles

8. To install, reverse the removal procedure.