


Power Running Board (PRB) Module


 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	14C177 14C177	Power Running Board (PRB) module
2	—	PRB module electrical connectors

Removal and Installation

1. Remove the C-pillar trim panels. For additional information, refer to Section 501-05.
2. Remove the 3 rear sound insulator pin-type retainers and remove the rear sound insulator.



3. Disconnect the Power Running Board (PRB) module electrical connectors.
4. Remove the PRB module.
5. To install, reverse the removal procedure.