

Rear View Mirrors



Exterior Mirrors

Aero Exterior Mirrors

The main serviceable components of the aero exterior mirrors are:

- Exterior mirror glass
- Exterior mirror plastic housing
- Exterior mirror control switch (optional)
- Heated exterior mirror glass (optional)
- Exterior mirror glass (blind spot optional, LH only)
- LH auto-dimming exterior mirror glass (optional)
- Exterior mirror glass adjustment motors (optional)
- Exterior mirror cover (plastic, chrome or painted)
- Exterior mirror glass adjustment motors (optional — with memory)
- Exterior mirror glass adjustment motor (manual) (standard)
- Exterior mirror puddle lamps (optional)
- Exterior mirror turn signals (optional)

Trailer Tow Exterior Mirrors

The main serviceable components of the trailer tow exterior mirrors are:

- Exterior mirror glass
- Exterior mirror spotter glass
- Heated exterior mirror glass (optional)
- Exterior mirror cover (optional — chrome or painted)
- Exterior mirror control switch (optional)
- Exterior telescoping mirror control switch (optional — part of the exterior mirror control switch)
- Exterior mirror glass adjustment motors (optional — power mirrors only)
- Exterior mirror puddle lamps (optional)
- Exterior mirror turn signals (optional)
- Exterior mirror side marker (optional — telescoping mirrors only)
- Exterior mirror fold relay (power folding with telescoping mirrors only)
- DSM (optional — memory exterior mirrors)

Interior Mirror

Interior Rear View Mirrors

The vehicle may be equipped with one of the following interior rear view mirrors:

- Interior rear view mirror
- Interior auto-dimming rear view mirror with compass
- Interior auto-dimming rear view mirror with video display
- Interior auto-dimming rear view mirror with compass and video display