


Exterior Mirror Control Switch — Trailer Tow



Removal and Installation

1. Lift upward and remove the exterior mirror trim panel.
 - Disconnect the electrical connectors.



2. Depress the locking tabs and remove the exterior mirror control switch.
3. To install, reverse the removal procedure.