

Memory Set Switch



Removal and Installation

NOTE: *For parts identification and location, refer to Seat — Exploded View, Front in this section.*

1. Remove the side shield insert.
 - Release the lower retainers and lift to release the upper retainers.
 - Disconnect the seat control switch electrical connector.
 - Disconnect the memory SET switch electrical connector.
2. Release the retaining tabs and remove the switch.
3. To install, reverse the removal procedure.