

Seat Backrest Thermo-Electric Device



Removal and Installation

NOTE: *For parts identification and location, refer to Seat — Exploded View, Front in this section.*

1. Position the seat backrest fully forward.
2. Release the backrest cover J-clip and unzip the 2 zippers.
3. Disconnect the Thermo-Electric Device (TED) electrical connector.
4. Detach the pin-type retainer attaching the TED duct to the backrest frame.
5. Un-hook the TED from the backrest support wire and remove.
 - If equipped with power lumbar, note cable routing for correct installation.
6. To install, reverse the removal procedure.