

Door Glass Top Run — Rear, SuperCab



Removal and Installation

1. Position the rear door window glass in the full downward position.
2. Remove the rear door trim panel. For additional information, refer to Section 501-05.
3. Remove the rear door interior moulding.
4. Remove the rear door window glass top run.
 - Remove the rear door window glass top run through the top opening of the rear door.
5. To install, reverse the removal procedure.