

Connecting Rod Large End Bore



NOTE: Refer to the appropriate Section 303-01 for the specification.

1. Tighten the bolts to specification, then measure the bore in 2 directions. The difference is the connecting rod bore out-of-round. Verify the out-of-round is within specification.

